


## Care for your Flute



Keep bore of instrument free from dirt and dust by swabbing occasionally with cleaning rod and soft cloth. Be sure that the rod is completely covered by the cloth to avoid scratching or gouging the inside of the instrument. Never use water because it will damage the pads.

A small soft brush can be used to remove dust and lint that gathers around the posts and springs and under key rods.

Wipe fingerprints off the body and keys of the instrument after playing and before putting the instrument in its case.

A silver polishing cloth is recommended, but no other cleaning agent may be used.

It is important to let the teacher tune the instrument. The teacher will let you know when you are able to tune the instrument yourself.

**If you encounter any problems with your instrument seek advice from the Music Centre, or your child's instrument teacher.**